

CE DECLARATION CONFORMITY.

Werku® declares that the WK501110 airless electric equipment is in accordance with the following Directives and Standards:

- 2006/42/EC
- 2006/95/EC
- EN 55014-1-2:2006+A1+A2
- EN 55014-2:2015
- EN 61000-3-2:2014
- EN 61000-3-3:2013
- EN 12821:2006+A1:2010
- EN 60204-1:2006+A1:2009
- EN 60204-1:2006/AC:2010
- EN 60034-1:2010
- EN 60034-5:2001-A1:2007

La Coruña, 01/11/2023
 R Yáñez
 Werku Tools SA

TECHNICAL CHARACTERISTICS.

Voltage-frequency	230 V-50 Hz
Power	2.2HP / 1600 W
Protection degree	IP23
Working pressure	120-180 bar
Maximum pressure	225 bar
Thread NPS	1/4"
Flow	3 l/min-1
Tip diameter	0.023"
Working temperature	5-40°C
Hose length	15 m
Net weight	16.6 kg
Acoustic pressure LpA	80 dB(A)
Acoustic pressure LWA	95 dB(A)
Vibration Aw for spray gun	0.5 m/s²

VIBRATION.

The declared vibration total value has been measured in accordance with a standard test method and may be used for comparing one power tool with another. The declared vibration total value may also be used in a preliminary assessment of exposure. Warning: vibration emission during actual use of the power tool can differ from the declared total value depending on the ways in which the power tool is used. Warning: identify safety measures to protect the operator, based on an estimation of exposure in the actual conditions of use.

PICTOGRAMS.

- Read instruction manual
- Wear eye protection
- Wear hand protection
- Wear ear protection
- Wear respiratory protection
- Hot surface warning
- Skin injection hazard
- Double insulation
- European conformity
- 2002/96/CE Directive - Waste Electrical and Electronic Equipment

SAFETY INSTRUCTIONS.

This power tool is intended to function as a airless electric equipment. Read all safety warnings, instructions, illustrations and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury. Keep all warnings and all instructions for future reference. Accidents can be avoided in many cases by recognizing a potentially hazardous situation before it occurs and by observing appropriate safety procedures. Operations for which this power tool was not designed may create a hazard and cause personal injury.

WORK AREA SAFETY.

Keep work area clean and well lit. Cluttered and dark areas invite accidents. Do not operate this power tool near flammable materials. Sparks could ignite these materials. Keep away from children and curious while operating a power tool. Distractions can cause you to lose control. Keep bystanders a safe distance away from work area.

Anyone entering the work area must wear personal protective equipment. Fragments of work piece or of a broken accessory may fly away and cause injury beyond immediate area of operation.

PERSONAL SAFETY.

Stay alert, watch what you are doing and use common sense when operating this power tool. Do not use this power tool while tired or under the influence of drugs, alcohol or medicines. A moment of inattention while operating this power tools may cause damage serious personal.

USE PPE'S.

Wear protective glasses according to EN166. Wear protective gloves according to EN420 or EN388. Wear hearing protection according to EN149. If the respiratory protection according to EN149. If the type of work requires it, use other precise PPE.

DO NOT WORK ON TIPTOES.

Keep your feet on the ground and balance at all times. This enables better control of the power tool in unexpected situations.

DRESS PROPERLY.

Do not wear loose clothing or jewelry. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewelry or long hair can be caught in moving parts. If there are devices for connecting means for extracting and collecting dust, make sure they are connected and properly used. The use of these devices can reduce dust related hazards.

ELECTRICAL SAFETY.

The plug of this power tool must match with the base of the socket. Never modify the plug in any way. Do not use any adapter plug with earthed power tools. Unmodified plugs and matching bases will reduce the risk of electric shock. Avoid body contact with grounded surfaces such as pipes, radiators, cookers and refrigerators. There is an increased risk of electric shock if your body is grounded. Do not expose this power tools to rain or wet conditions. Water entering this power tool will increase the risk of electric shock. Hold this power tool by insulated gripping surfaces only, when performing an operation where the spinning accessory may contact hidden wiring or its own cord. A spinning accessory contacting a "live" wire may make exposed metal parts of this power tool "live" and could give the operator an electric shock. Do not use accessories

that require liquid coolants. Using water or other liquid coolants may result in electrocution or shock.

DO NOT ABUSE THE CORD.

Never use the cord to carry, lift or unplug this power tool. Keep the cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock. When operating this power tool outdoors, use an extension cord suitable for outdoor use. The use of an extension cord suitable for outdoor use reduces the risk of electric shock. If the use of this power tool in a damp location is unavoidable, use a power protected by a residual current device (RCD). The use of an RCD reduces the risk of electric shock.

AVOID ACCIDENTAL STARTING.

Make sure the switch is in "off" position before connecting to the network, or when taking or carrying this power tool. Carrying power tools with your finger on the switch or plugging in power tools that have the switch in "on" position invites to accidents. Remove keys or tools before starting the power tool. A left key or tool attached to a rotating part of a power tool can cause personal injury. Never lay this power tool down until the accessory has come to a complete stop. Do not run this power tool while carrying it at your side.

USE AND CARE.

Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was conceived. Do not use the power tool if the switch cannot be positioned to "off" and "on" position. Any power tool that cannot be controlled with the switch is dangerous and must be repaired. Remove the plug from the power supply and/or battery before making any adjustments, changing accessories or storing the power tool. Such preventive safety measures reduce the risk of starting the power tool accidentally. Do not use accessories which are not specifically designed and recommended by Werku®. Just because the accessory can be attached to this power tool, it does not assure safe operation. Do not use a damaged accessory. Before each use, inspect the accessory. If this power tool or its accessory is dropped, inspect for damage or install an undamaged accessory. Regularly clean this power tool's air vents. The motor's fan will draw the dust inside the housing and excessive accumulation of powdered metal may cause electrical hazards.